

CST5015 CARAVAN & MOTORHOME WINDOW RUBBER COVER STRIP FITTING TOOL



Our caravan and motorhome cover strip fitting tool helps simplify the fitting of the cover strip into double glazed opening window rubbers.

1

Lubricate the inside of the rubber window seal with silicone spray (SS4363).

2

Insert the tool into the rubber seal under the cover strip securing lips.

3

Insert the grey or white cover strip through the centre of the tool and push the end into the rubber under the lips.

4

Gently move the tool forward to lay the cover strip into the rubber. Continue all the way around the window.

VIDEO DEMO

For a video demonstration, watch our YouTube video at

www.youtube.com/watch?v=kyw5ZDrw7xl

